SGVL Schneider Globe Valve Linkage

For use with LV and SV Series Actuators







Technical Data		
Service	chilled or hot water and steam	
Applicable valve size	½" [13], ¾" [19], 1" [25], 1-¼" [32], 1-½" [38], 2" [50]	
Frame, plate, base	aluminum	
Collar*	aluminum	
	(fits VB7 1/2" to 2"/VB9 1/2" to 1-1/4" valves)	
Coupling	aluminum	
Stem adaptor	steel	
Stroke	0.75" [20 mm]	
Mounting position	360°	
Media temp range (water)	20°F to 250°F [-7°C to +120°C]	
Media temp range (steam)	20°F to 250°F [-7°C to +120°C]	
Housing material	aluminum die cast and plastic casing	
Weight	0.5 lbs	
*Will also fit post 1004 VPO 1	16" to 0" volves	

*Will also fit post 1994 VB9 1-1/2" to 2" valves.

Application

The SGVL retrofit kit is designed to easily attach LV and SV series actuators to select Schneider[®] globe valves. The cast base and free spinning collar allow the SGVL to be mounted on $\frac{1}{2}$ " to 2" two-way or three-way valves in both normally open and normally closed configurations.

Default/Configuration

The default set up for a SGVL linkage will be factory installed along with a LV or SV series actuator. Included in the kit is all the necessary hardware to facilitate mounting to the Schneider valve.


Operation

The SGVL linkage with actuator will provide 20 mm of linear travel to accommodate a wide range of valve sizes.


Suitable Actuators

Linkage	Non-Spring Return	Electronic Fail-Safe
SGVL	LV, SV	LVK, SVK

Dimensions (Inches [mm]) with LV and SV Series Actuators



Dimensions (Inches [mm]) with LVK and SVK Series Actuators



-		
Α	В	C
6.7" [169]	3.9" [98]	8.2" [209]


Application Notes

**Consult pages 92-134 of the Retrofit Technical Documentation and/or SelectPro for close-off pressures and a cross reference of each valve.



Phone (877) 632-4876





† Use flexible metal conduit. Push the Listed conduit fitting device over the actuator's cable to butt against the enclosure. Screw in conduit connector. Jacket the actuators input wiring with Listed flexible conduit. Properly terminate the conduit in a suitable junction box. Rated impulse Voltage 800V. Type of action 1. Control Pollution Degree 3.

Application

Fail-safe for multiple control types of globe valves in HVAC steam and hydronic systems.

Actuator sizing will be dictated by the valve size selection. All valve selections should be done in accordance with the flow parameters and system specifications. The actuator is mounted directly to the globe valve bonnet by means of its universal clamp and collar.

The actuator operates in response to many controls types as desired by the customer and/or design control input from an electronic controller or positioner. A 2 to 10 VDC feedback signal is provided for position indication.

Operation

The actuator is not provided with and does not require any limit switches, but is electronically protected against overload. The SVK series provides 20 mm of downward travel and a visual indicator indicates position of the actuator. When reaching the valve end position, the actuator automatically stops. The gears can be manually disengaged with a button on the actuator cover.

The SVK... series actuators use a sensorless brushless DC motor. The ASIC inside monitors and controls the actuator's rotation and provides a digital rotation sensing (DRS) function to prevent damage to the actuator in a stall condition. Power consumption is reduced in holding mode.

Add-on auxiliary switches are easily fastened directly onto the actuator body for signaling and switching functions. -SR and –MFT models will have an illuminated green Adaption/Power button to reset and relearn the valve stroke as well as indicate the actuator is powered. This feature allows the actuator to rescale itself based on the actual travel. Along with the Adaption button on –MFT models will have a yellow Status light to confirm communication.

Fail-Safe Indication

LED status indicator lights sequence:

Yellow off / Green on: operation ok, no faults

Yellow off / Green blinking: fail-safe mechanism is active


Yellow on / Green off: fault is detected

Yellow off / Green off: not in operation / capacitors charging

Yellow on / Green on: adaption running

Yellow blinking / Green on: communication with programming tool

Dimensions (Inches [mm])



P10401 - 01/13 - Subject to change. © Belimo Aircontrols (USA), Inc




SVKX24-MFT

Typical Specification

Proportional control globe valve actuators shall be electronic and direct coupled to the globe valve bonnet via an integrated linkage, which requires no secondary linkage and be capable of mounting to valves 1/2" to 2" in size. Actuators must provide control in response to a control input from an electronic controller or positioner. Actuators shall have brushless DC motor technology and be protected from overload at all angles of rotation. Actuators shall have reversing switch and manual override on the cover. Run time shall be constant and independent of torque. Actuators shall be cULus listed, have a 5-year warranty, and be manufactured under ISO 9001 International Quality Control Standards. Actuators shall be as manufactured by Belimo.

Wiring Diagrams



During installation, testing, servicing and troubleshooting of this product, it may be necessary to work with live electrical components. Have a qualified licensed electrician or other individual who has been properly trained in handling live electrical components perform these tasks. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.

