

Repair Parts for Cage Trim Valve for Use with V-3754 with Actuator and VB-3754 without Actuator (Including 1/2 in.)

Description

The available service parts listed in the tables can extend the service life of the V-3754 and VB-3754 cage trim valve assemblies and in many cases return the valve to near original operating performance.

Selection Charts

Note: 1/2 inch valve assemblies discontinued in 1991.


VB valves used with AV-8050, AV-8051, AV-8052, AV-8090, AV-8091,

and AV-8092 assemblies.

Springs are under compression.

Removal of springs requires use of spring compression tool JC 5389.

Code Number	Callout	Description	V-3754	VB-3754	
V-3752-646	Α	Gland Nut (Pack	Х	X	
V-9999-608	В	Packing Kits			X
V-9999-610			10 pack (contains enough materials to repack 10 valves)	Х	Х
V-9999-630			50 pack (contains U-cups and O-rings only to repack 50 valves)	Х	Х



Repair Parts, V-3754 and VB-3754

Spring Kits and Recondition Kits for use with V-3754 and VB-3754

Valve	Valve Size	Actuator Size	Spring Range	Spring Kit ¹ Code Number	Recondition Kits ² Code Number	
_	1/2 in.	V-3000	3-6 psig	V-3754-6010	V-3754-6003 (C _V = 0.20), or	
			9-13 psig	V-3754-6009	V-3754-6004 (C _V = 0.40) or V-3754-6005 (C _V = 1.20), or V-3754-6006 (C _V = 2.20) or V-3754-6007 (C _V = 4.40)	
	3/4 in.		3-6 psig	V-3754-6010	V-3754-6001 (C _V = 8.6)	
			9-13 psig	V-3754-6009	1	
	1 in.		3-6 psig	V-3754-6011	V-3754-6002 (C _V = 13.9)	
			9-13 psig	V-3754-6008	1	
	1-1/2 in.	1	3-6 psig	V-3754-6011	V-5254-6001 (C _V = 27.5)	
			9-13 psig	V-3754-6008		

Spring Kit includes: upper and lower spring plate, spring, stem connector, stem lock screw, and instructions

^{2.} Recondition Kit includes: cage, O-ring, plug, stem, bonnet, packing, packing nut, and instructions

